

Select or deselect videos for recording

Aim

To choose from which video sources to record video files.


Prerequisite

You selected the recording devices in the **Video Settings** window.

See [Select a video device](#)

Procedure

Select or deselect video sources for recording in the **Use** column.



Revision #5

Created 29 November 2023 21:38:53

Updated 20 December 2023 12:47:08