Select or deselect videos for recording

Aim

To choose from which video sources to record video files.


Prerequisite

You selected the recording devices in the **Video Settings** window.

See Select a video device

Procedure

Select or deselect video sources for recording in the **Use** column.



Revision #5
Created 2023-11-29 21:38:53 UTC
Updated 2023-12-20 12:47:08 UTC